



USE THIS TEMPLATE TO ALIGN YOUR LETTERS

-INSTALL LETTERS BEFORE INSTALLING TSO PRO GRILLE TO 4RUNNER

- 1) CUT ALONG THE BOTTOM EDGE OF LETTERS ON THE TEMPLATE
- 2) TRANSFER TEMPLATE TO CARDBOARD, USE THE TOP EDGE OF PAPER TO ALIGN WITH A STRAIGHT EDGE OF CARDBOARD. TOP EDGE OF PAPER IS THE PROPER SPACING FROM THE TOP OF THE TSO PRO GRILLE. CUT OUT TRANSFERRED TEMPLATE.
- 3) INSTALL SUPPLIED TAPE TO BACK OF LETTERS. WIPE DOWN BACKS OF LETTERS WITH ISOPROPYL ALCOHOL. CUT TAPE TO LENGTHS AS NEEDED. KEEP TAPE CLEAN AND FINGER PRINT FREE. PRESS TAPE FIRMLY FOR 30 SECONDS TO BACK OF LETTERS. DO NOT PEEL RED PROTECTIVE PLASTIC UNTIL YOU ARE READY TO MOUNT THE LETTER. TO PEEL PROTECTIVE PLASTIC GENTLY LIFT OFF OF ONE CORNER AND PEEL IT OFF. DO NOT TOUCH ADHESIVE.
- 4) USING 3/4" MASKING TAPE. PLACE TAPE ON THE TOP EDGE OF THE LETTER MOUNTING SURFACE. MEASURE AND MARK CENTER LINE ON TSO PRO GRILLE AND TEMPLATE, AND WIPE DOWN TSO PRO GRILLE WITH ISOPROPYL ALCOHOL ON A MICROFIBER TOWEL.
- 5) ALIGN YOUR CENTER MARKS AND TEMPORARILY TAPE TEMPLATE TO COVER. PLACE YOUR FIRST LETTER T THE BOTTOM OF THE TAPE GUIDE AND USING TEMPLATE TO GET PROPER PLACEMENT. YOU NO LONGER NEED TO LEAVE TEMPLATE ATTACHED. YOU CAN JUST USE IT AS A QUICK REFERENCE FOR EACH LETTER PLACEMENT. PLACE EACH LETTER AT THE BOTTOM OF THE GUIDE TAPE
- 6) ATTACH LETTERS TO TSO PRO GRILLE, MAKE SURE THE LETTERS ARE FIRMLY FITTED. PRESS FROM BEHIND THE LETTERS TO LET THE TAPE MAKE FULL CONTACT WITH TSO PRO GRILLE. HOLD FOR 30 SECONDS

INSTALLER IS FULLY RESPONSIBLE FOR INSTALLATION. THERE ARE NO WARRANTIES OR GUARANTEES ON ANY AND ALL PRODUCTS OR SUPPLIES SOLD, SUPPLIED OR MANUFACTURED BY TRAIL STANDARD OFFROAD. INSTALL AT YOUR OWN RISK.