

# TSO PRO GRILLE COVER INSTALLATION

1)REMOVE UPPER GRILL

2)CLEAN CENTER SECTION WHERE COVER ATTACHES WITH SOAP AND WATER  
-THEN WIPE DOWN CENTER SECTION WITH RUBBING ALCOHOL.

3)AFTER ALLOWING TIME FOR CENTER SECTION TO DRY. PEEL PLASTIC FILM FROM ADHESIVE STRIPS ON THE FRONT INNER SURFACE OF COVER.  
-FOR THE ADHESIVE STRIP ON THE TOP PORTION OF TSO PRO COVER. MAKE A SMALL INCISION TO THE CENTER OF THE PLASTIC FILM. THEN PEEL BACK JUST A FEW INCHES ON EACH SIDE FROM THE CENTER. TAPE THE PEELED PLASTIC TO THE TOP SURFACE OVER THE TSO COVER.

4)YOU ARE NOW READY TO INSTALL THE TSO PRO GRILLE COVER. MAKING SURE THE COVER IS CENTERED. PLACE COVER ONTO CENTER SECTION. STARTING FROM THE CENTER PRESS FIRMLY ACROSS THE FRONT OF THE COVER. WORK FROM BOTTOM TO TOP AND FROM CENTER TO THE OUTER EDGES.

5)AFTER YOU HAVE FULLY SEATED THE ADHESIVE TO FRONT OF THE COVER. IT IS NOW TIME TO COMPLETELY PEEL THE PLASTIC STRIPS TAPED TO THE TOP FROM STEP 3. REMOVE STRIPS AND FIRMLY PRESS DOWN ON TO THE TOP OF TSO PRO COVER. WORK FROM THE CENTER TO THE OUTER EDGE.

6)INSTALL UPPER GRILLE WITH OEM TRD PRO GRILL ATTACHED.

BASICALLY INSTALLATION IS IDENTICAL TO THE OEM TRD PRO GARNISH. FEEL FREE TO GOOGLE/YOUTUBE INSTALLS OF THE OEM GARNISH IF NEED FURTHER INSTRUCTION.

THIS GUIDE IS ONLY MEANT FOR INSPIRATIONAL PURPOSES ONLY. INSTALLER ASSUMES ANY AND ALL RESPONSIBILITIES ASSOCIATED WITH TSO PRO GRILLE THERE ARE NO WARRANTIES AND/OR GUARANTEES ON PRODUCTS AND SUPPLIES SOLD, PROVIDED, AND/OR MANUFACTURED BY TRAIL STANDARD OFFROAD. INSTALL AT YOUR OWN RISK.